



3-9x40MM SCOPE



Item # DR2704

Complete Installation & Operating Instructions

Mounting the Scope

- There are two ring mounts that are provided with this scope. These may or may not work with your current application. Please consult your local firearms dealers if you are unsure or have any questions pertaining to mounting the scope.
- To separate the rings use the provided Allen key and take off the top portion of the rings by removing the four Allen screws on each ring.
- Place scope in the lower ring cradles and begin to put the tops back on the ring cradles. In this operation please only finger tighten. Scope should be able to move freely at this point for adjustment purposes.
- Loosen the mounting screws on the base of the scope rings and mount to the rail of the gun.
- Put the rifle to your shoulder in your natural shooting position and adjust the scope towards your or away from you to obtain the best eye relief. This goal is achieved when you have a full field of view while looking down the scope.
- After adjusting the eye from above please rotate the scope to make sure that the image and/or crosshair on the scope are vertical and perpendicular to the gun.
- When all adjustment is completed please tighten all screws to ensure a firm grip on the scope



DO NOT OVERTIGHTEN THE SCREWS AS YOU COULD CAUSE PERMANENT DAMAGE TO THE INTERNAL FUNCTIONS OF THE SCOPE AND THE SCOPE BODY.

WARNING: If a scope is mounted too far to the rear, the eyepiece can injure the shooter's brow. Therefore, when mounting your scope, we recommend positioning it as far forward in the mounts as possible to take full advantage the eye relief provided.

BEFORE READING FURTHER, PLEASE MAKE SURE YOUR FIREARM IS UNLOADED AND THE SAFETY IS ON.

A note about the warnings and information contained in this manual:

We strongly suggest that you check with your local licensed retailer or state police for additional information concerning firearms ownership, or hunting or target shooting rules that may be required by local law or regulation. Since such rules and regulations are subject to change, local authorities are in the best position to advise you on such matters.

IMPORTANT "SAFETY WARNINGS" — NOTE THE SYMBOL THESE SAFETY WARNINGS ARE FOR YOUR PROTECTION AS WELL AS THE SAFETY OF OTHERS. DISREGARDING INFORMATION IN THIS MANUAL MAY RESULT IN SERIOUS INJURY OR DEATH.



Be certain the owner's manual for your firearm is available for reference when preparing to install any Dead Ringer Shooting Sports Products. If the original firearm manufactures manual is lost or misplaced, please contact the manufacturer or a certified gunsmith before attempting to handle your firearm.



After performing any work on your firearm such as mounting, adjusting, calibrating, cleaning, assembly, disassembly or installation of any accessory, the firearm should be re-checked for proper functioning before firing live ammunition.



Firearms are complex mechanisms. Any modification, alteration, or improper fitting of parts may result in a dangerous malfunction, damage to the firearm, and injury to the shooter and/or others nearby. The firearm's owner must accept full responsibility for the correct reassembly and functioning of the firearm after any disassembly or replacement of parts.



If you do not understand any of the material in this manual or have any questions, contact the Original Firearm Manufacturing Product Service Center or a qualified gunsmith.



Do not attempt to load, handle or use the firearm until you read and understand the information contained in its owner's manual. Before handling your firearm, you should learn how it operates and how to maintain it. This includes knowing its basic parts, how the manual safety and other safety features operate, how to safely open and close the action and how to safely load and unload ammunition from the firearm. Improper use and handling is dangerous and could cause serious injury or death to you or those around you. All users of the firearm must become thoroughly familiar with the instructions in this manual.

AS THE OWNER OF A FIREARM, YOU MUST UNDERTAKE THE FULL-TIME RESPONSIBILITY OF SAFE FIREARMS HANDLING FOR YOUR OWN SAFETY AND THE SAFETY OF THOSE AROUND YOU:

- KEEP ALL FIREARMS AND AMMUNITION OUT OF THE REACH OF CHILDREN.
- STORE YOUR FIREARMS AND AMMUNITION SEPARATELY.
- NEVER STORE A LOADED FIREARM.
- NEVER LEAVE A LOADED FIREARM UNATTENDED.
- NEVER TRANSPORT A LOADED FIREARM IN A VEHICLE.
- UNLOAD YOUR FIREARM WHEN YOU HAVE STOPPED SHOOTING AND WHEN YOU HAVE TO CLIMB A TREE, FENCE, CROSS A SLIPPERY SURFACE OR HAVE TO TRANSPORT IT IN A VEHICLE.
- DO NOT LOAD YOUR FIREARM BEFORE YOU ARE IN A PLACE WHERE IT IS SAFE TO SHOOT, AND KEEP YOUR FINGER OFF THE TRIGGER UNTIL YOU ARE ON TARGET AND HAVE DECIDED TO FIRE.
- NEVER SHOOT AT WATER, ROCKS OR ANY HARD SURFACES. BULLETS MAY GLANCE OFF SUCH SURFACES AND CAUSE INJURIES.
- DO NOT USE ALCOHOL OR DRUGS BEFORE OR WHILE HANDLING FIREARMS.
- DO NOT TOUCH THE TRIGGER WHILE THE SAFETY SELECTOR LEVER IS BEING ENGAGED OR DISENGAGED.

Always point the muzzle of your firearm in a safe direction, regardless of whether the firearm is loaded or unloaded. You should become thoroughly familiar with the function and operation of this firearm and the instructions supplied with it.

Always treat every firearm as if it is loaded. Give your firearm to someone with the action open (bolt fully rearward), and the safety selector lever fully to the "ON" (SAFE) position, after you verify the firearm is unloaded. Insist on the same procedure when receiving a firearm from someone else. Learn the location of all the safety features of your firearm and how they operate.

Wear eye and ear protection when shooting. Shooting without proper ear protection can cause hearing damage. The use of eye protection during anytype of shooting is important to protect your vision.

When using a firearm with mounted optics, maintain an adequate distance between the rear of the scope and your face at all times. Be certain the scope installation does not interfere with access to, or the proper functioning of the safety selector lever.

We specifically disclaim responsibility for any damages or injury whatsoever occurring in connection with, or as a result of, the use of faulty, or non-commercially manufactured, or remanufactured or hand-loaded (reloaded) ammunition. Additionally, we disclaim any responsibility for damage or injury which results from any modifications or changes that are not a part of a firearm as delivered from the factory. We specifically disclaim responsibility for any damages or injury whatsoever occurring in connection with the use of a firearm in conjunction of any Dead Ringer Shooting Sports Products. Dead Ringer does not warrant that this product is commercially viable and we hereby disclose that it has not been tested or approved for use in conjunction with any firearm by any governing body or authority, independent laboratory and or any other public or private testing institutions.


We specifically disclaim responsibility for any damages or injury whatsoever occurring in connection with the use of a firearm. Dead Ringer does not suggest making any modifications or customizations to any firearm whatsoever.

Specifications – Model 3-9x40MM

Magnification	3.15x-9.35x	W/E Adjust Click Value	1/4 MOA at 100 Yards
Reticle	Metal	Length (inch/mm)	12.2 / 310
Exit Pupil	8.1~4.1mm	Weight	12.7 oz
Eye Relief (inch/mm)	3.46-2.76 / 88-70	Tube Diameter	1"

DR2704

Reticle Shown Below



Scope Parts

- Ocular Lens
- Windage (horizontal) Adjustment
- Elevation (vertical) Adjustment
- Power Selector Ring
- Objective Lens



Maintenance Instructions

Remember to always keep your scope lenses as clean as possible during use. Never clean debris and marks from scope lenses by rubbing with a dry cloth or tissue. You should always moisten the lens before wiping, and always brush loose material from the lens surface using a lens brush. Always clean the lens with non-abrasive cleaning fluid and then wipe clean in circular motions. All moving parts of the scope are permanently lubricated. Do not try to lubricate them. No maintenance is needed on the scope's outer surface, except to occasionally wipe off dirt or fingerprints with a soft cloth using water.

NOTE – Power Selector Ring

If your scope is equipped with a power selector ring, no lubrication is ever required on the ring itself. Never loosen the flat head screw on the power selector ring. This will cause the loss of internal gas that is put in to keep the scope fog free.

Warranty

Limited Warranty: Dead Ringer warrants to you, the original retail purchaser, that the Dead Ringer product will be free of defects in material or manufacture for a period of one (1) year from the date of your purchase of the new product (the "Warranty Period") in the United States or Canada. This is the only express warranty on the Dead Ringer. **DEAD RINGER MAKES NO OTHER WARRANTIES OF ANY KIND OR CONDITIONS, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** This Limited Warranty gives you specific legal rights, and you may have other rights that vary from State to State. Purchaser's Remedy: During the Warranty Period, Dead Ringer will, at its sole option, (1) repair the Dead Ringer product or any part thereof that, upon examination and testing by Dead Ringer, does not conform to the Limited Warranty without charge to you for parts or labor, or (2) replace the Dead Ringer product with a new or similar model.

THIS REMEDY SHALL BE YOUR EXCLUSIVE AND SOLE REMEDY FOR ANY BREACH OF WARRANTY. D.R. OUTDOORS GROUP SHALL NOT BE RESPONSIBLE FOR ANY OTHER EXPENSES, LOSSES OR INCONVENIENCE THAT YOU MAY SUSTAIN AS A RESULT OF THE PURCHASE, USE, MALFUNCTION OR DEFECTIVE CONDITION OF THE DEAD RINGER SHOOTING SPORTS PRODUCT.

Dead Ringer reserves the right to inspect, examine and/or test the Dead Ringer product to assess any claim made under the Limited Warranty.

EXCLUSIONS: THIS WARRANTY DOES NOT COVER THE COSMETIC APPEARANCE OF THE DEAD RINGER SHOOTING SPORT PRODUCT OR ANY DAMAGE CAUSED BY:

- NORMAL WEAR AND TEAR
- FAILURE TO PERFORM PROPER CARE AND MAINTENANCE
- ACCIDENTS, ABUSE OR NEGLIGENCE
- FAILURE TO FOLLOW THE INSTRUCTIONS AND WARNINGS THAT ACCOMPANY THE DEAD RINGER SSP.

IN ADDITION, ANY UNAUTHORIZED REPAIRS, ALTERATIONS OR MODIFICATIONS TO THE DEAD RINGER SHOOTING SPORT PRODUCT WILL AUTOMATICALLY VOID THE LIMITED WARRANTY.

LIMITATION OF DAMAGES: EXCEPT WHERE PROHIBITED BY LAW, DEAD RINGER WILL NOT BE LIABLE FOR ANY LOSS OR DAMAGE WHATSOEVER ARISING FROM THE USE OF THIS DEAD RINGER SHOOTING SPORT PRODUCT, WHETHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE, REGARDLESS OF THE LEGAL THEORY ASSERTED, INCLUDING CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY. SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

Warranty Service

To obtain service under this Limited Warranty, you must follow the instructions listed: Products must be brought back to the original authorized retailer where the product was purchased. Your return will only be evaluated by the retailer if the original receipt is provided and represents that the product is still covered under the "Limited Warranty" time period. In the event that the retailer is no longer in business, the owner (YOU) are responsible for all shipping costs to send the item back to the Dead Ringer Product Service Center. Dead Ringer will not accept COD shipments of any Dead Ringer Products for service. After repair or replacement, the Dead Ringer SSP or a similar model will be returned to you, return postage paid by Dead Ringer. If we replace the Dead Ringer SSP, Dead Ringer will keep the original unit that was returned to the Dead Ringer Product Service Center.

Modification of Warranty: No agent, representative, distributor, or authorized dealer of Dead Ringer Shooting Sports has any authority to modify the terms or conditions of the Limited Warranty in any way. The Limited Warranty may only be modified in writing by an authorized officer of D.R. Outdoors Group.



RockRidgeOUTDOORS.COM

Manufactured for Dead Ringer
Rock Ridge Outdoors, LLC
148 Country Club Circle
Minden, LA 71055

Phone: (844) 471-4868



Copyright © 2021, Dead Ringer
DEAD RINGER reserves the right to change products, specifications, models and prices without notice.
DEAD RINGER products are protected by one or more US and foreign patents.