



RockRidgeOutdoors.com

Manufactured for Dead Ringer  
Rock Ridge Outdoors, LLC  
148 Country Club Circle  
Minden, LA 71055  
Made in China



Tel.: (844) 471-4868

## Zeroing

**Caution: Please use proper hearing and eye protection at all times whenever firing a weapon.**

### IMPORTANT

Before making any adjustments to the windage and elevation, be sure to loosen the locking screw on the side of the base to avoid damage to the internal components of the sight using the provided screwdriver (marked lock zero). When you have finished zeroing your sight, tighten the locking screw on the base to hold your zero position (marked lock zero).

It is extremely important to adjust the intensity of the reticle to the current light conditions. For example: During daylight use the intensity should be set on the higher settings (dial setting 3, 4 or 5 on dial). Low-light or night time conditions the intensity should be set to the lower settings (dial setting 1 or 2 on dial). Please keep in mind that if the intensity is adjusted too high for the light conditions it may cause either a distorted or double view of the reticle.

Select the reticle you desire by turning the reticle adjustment switch and set the intensity for the current light condition. After the installation of the sight, rest the gun on a solid support and set up your target at your desired yardage. Test shots should be done in the same conditions to achieve maximum accuracy for adjustment. Each click adjustment moves the point of impact by 1 MOA (approximately 1" at 100 yds, 1/2" at 50 yds).

Picture below illustrates reticles provided.



## Battery Replacement

The Green Dot is powered by one 3V lithium battery (CR2032 or equivalent). If the reticle shows signs of dimming or does not light up that means it is time to replace the battery. To replace the battery unscrew the battery cover (as seen in diagram) and replace the battery with the + (positive) side up.



Turn Counterclockwise to Unscrew the Cover

## Care and Maintenance

- To clean the lenses on this product, please utilize the provided cleaning cloth to avoid any scratches that may affect the product performance.
- Remember to always check to see if the sight is secure before each use
- Any disassembly of the product besides battery replacement will void any type of warranty on the product.

## Warranty

Limited Warranty: D.R. Outdoors Group and Rock Ridge Outdoors, LLC warrants to you, the original retail purchaser of a Dead Ringer product, that the Dead Ringer product will be free of defects in material or manufacture for a period of one (1) year from the date of your purchase of the new product (the "Warranty Period") in the United States or Canada. This is the only express warranty on the Dead Ringer product. DEAD RINGER MAKES NO OTHER WARRANTIES OF ANY KIND OR CONDITIONS, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This Limited Warranty gives you specific legal rights, and you may have other rights that vary from State to State. Purchaser's Remedy: During the Warranty Period, Dead Ringer will, at its sole option, (1) repair the Dead Ringer product or any part thereof that, upon examination and testing by Dead Ringer, does not conform to the Limited Warranty without charge to you for parts or labor, or (2) replace the Dead Ringer product with a new or similar model. THIS REMEDY SHALL BE YOUR EXCLUSIVE AND SOLE REMEDY FOR ANY BREACH OF WARRANTY. DEAD RINGER SHALL NOT BE RESPONSIBLE FOR ANY OTHER EXPENSES, LOSSES OR INCONVENIENCE THAT YOU MAY SUSTAIN AS A RESULT OF THE PURCHASE, USE, MALFUNCTION OR DEFECTIVE CONDITION OF THE DEAD RINGER PRODUCT.

Dead Ringer reserves the right to inspect, examine and/or test the Dead Ringer product to assess any claim made under the Limited Warranty.

EXCLUSIONS: THIS WARRANTY DOES NOT COVER THE COSMETIC APPEARANCE OF THE DEAD RINGER PRODUCT OR ANY DAMAGE CAUSED BY:

- (1) NORMAL WEAR AND TEAR;
- (2) FAILURE TO PERFORM PROPER CARE AND MAINTENANCE;
- (3) ACCIDENTS, ABUSE OR NEGLIGENCE;
- (4) FAILURE TO FOLLOW THE INSTRUCTIONS AND WARNINGS THAT ACCOMPANY THE DEAD RINGER SSP.

IN ADDITION, ANY UNAUTHORIZED REPAIRS, ALTERATIONS OR MODIFICATIONS TO THE DEAD RINGER SHOOTING SPORTS PRODUCT WILL AUTOMATICALLY VOID THE LIMITED WARRANTY.

LIMITATION OF DAMAGES: EXCEPT WHERE PROHIBITED BY LAW, DEAD RINGER WILL NOT BE LIABLE FOR ANY LOSS OR DAMAGE WHATSOEVER ARISING FROM THE USE OF THIS DEAD RINGER SHOOTING SPORTS PRODUCT, WHETHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE, REGARDLESS OF THE LEGAL THEORY ASSERTED, INCLUDING CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY. SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

Warranty Service: To obtain service under this Limited Warranty, you must follow the instructions listed below:

Products must be brought back to the original authorized retailer where the product was purchased. Your return will only be evaluated by the retailer if the original receipt is provided and represents that the product is still covered under the "Limited Warranty" time period. In the event that the retailer is no longer in business, the owner (YOU) are responsible for all shipping costs to send the item back to the Dead Ringer Service Center. Dead Ringer will not accept COD shipments of any Dead Ringer products for service. After repair or replacement, the Dead Ringer or a similar model will be returned to you, return postage paid by Dead Ringer. If we replace the Dead Ringer product, Dead Ringer will keep the original unit that was returned to the Dead Ringer product Service Center.

Modification of Warranty: No agent, representative, distributor, or authorized dealer of Dead Ringer has any authority to modify the terms or conditions of the Limited Warranty in any way. The Limited Warranty may only be modified in writing by an authorized officer of Dead Ringer or Rock Ridge Outdoors LLC.



Green Dot

Item # DR2711



RockRidgeOutdoors.com

**BEFORE READING FURTHER, PLEASE MAKE SURE YOUR FIREARM IS UNLOADED AND THE SAFETY IS ON.**

A note about the warnings and information contained in this manual:

We strongly suggest that you check with your local licensed retailer or state police for additional information concerning firearms ownership, or hunting or target shooting rules that may be required by local law or regulation. Since such rules and regulations are subject to change, local authorities are in the best position to advise you on such matters.

**IMPORTANT "SAFETY WARNINGS" — NOTE THE SYMBOL THESE SAFETY WARNINGS ARE FOR YOUR PROTECTION AS WELL AS THE SAFETY OF OTHERS. DISREGARDING INFORMATION IN THIS MANUAL MAY RESULT IN SERIOUS INJURY OR DEATH. ⚠**

⚠ Be certain the owner's manual for your firearm is available for reference when preparing to install any Dead Ringer Shooting Sports Products. If the original firearm manufactures manual is lost or misplaced, please contact the manufacturer or a certified gunsmith before attempting to handle your firearm.

⚠ After performing any work on your firearm such as mounting, adjusting, calibrating, cleaning, assembly, disassembly or installation of any accessory, the firearm should be re-checked for proper functioning before firing live ammunition.

⚠ Firearms are complex mechanisms. Any modification, alteration, or improper fitting of parts may result in a dangerous malfunction, damage to the firearm, and injury to the shooter and/or others nearby. The firearm's owner must accept full responsibility for the correct reassembly and functioning of the firearm after any disassembly or replacement of parts.

⚠ If you do not understand any of the material in this manual or have any questions, contact the Original Firearm Manufacturing Product Service Center or a qualified gunsmith.

⚠ Do not attempt to load, handle or use the firearm until you read and understand the information contained in its owner's manual. Before handling your firearm, you should learn how it operates and how to maintain it. This includes knowing its basic parts, how the manual safety and other safety features operate, how to safely open and close the action and how to safely load and unload ammunition from the firearm. Improper use and handling is dangerous and could cause serious injury or death to you or those around you. All users of the firearm must become thoroughly familiar with the instructions in this manual.

**AS THE OWNER OF A FIREARM, YOU MUST UNDERTAKE THE FULL-TIME RESPONSIBILITY OF SAFE FIREARMS HANDLING FOR YOUR OWN SAFETY AND THE SAFETY OF THOSE AROUND YOU:**

- Ⓢ KEEP ALL FIREARMS AND AMMUNITION OUT OF THE REACH OF CHILDREN.
- Ⓢ STORE YOUR FIREARMS AND AMMUNITION SEPARATELY.
- Ⓢ NEVER STORE A LOADED FIREARM.
- Ⓢ NEVER LEAVE A LOADED FIREARM UNATTENDED.
- Ⓢ NEVER TRANSPORT A LOADED FIREARM IN A VEHICLE.
- Ⓢ UNLOAD YOUR FIREARM WHEN YOU HAVE STOPPED SHOOTING AND WHEN YOU HAVE TO CLIMB A TREE, FENCE, CROSS A SLIPPERY SURFACE OR HAVE TO TRANSPORT IT IN A VEHICLE.
- Ⓢ DO NOT LOAD YOUR FIREARM BEFORE YOU ARE IN A PLACE WHERE IT IS SAFE TO SHOOT, AND KEEP YOUR FINGER OFF THE TRIGGER UNTIL YOU ARE ON TARGET AND HAVE DECIDED TO FIRE.
- Ⓢ NEVER SHOOT AT WATER, ROCKS OR ANY HARD SURFACES. BULLETS MAY GLANCE OFF SUCH SURFACES AND CAUSE INJURIES.
- Ⓢ DO NOT USE ALCOHOL OR DRUGS BEFORE OR WHILE HANDLING FIREARMS.
- Ⓢ DO NOT TOUCH THE TRIGGER WHILE THE SAFETY SELECTOR LEVER IS BEING ENGAGED OR DISENGAGED.

Always point the muzzle of your firearm in a safe direction, regardless of whether the firearm is loaded or unloaded. You should become thoroughly familiar with the function and operation of this firearm and the instructions supplied with it.

Always treat every firearm as if it is loaded. Give your firearm to someone with the action open (bolt fully rearward), and the safety selector lever fully to the "ON" (SAFE) position, after you verify the firearm is unloaded. Insist on the same procedure when receiving a firearm from someone else. Learn the location of all the safety features of your firearm and how they operate.

Wear eye and ear protection when shooting. Shooting without proper ear protection can cause hearing damage. The use of eye protection during any type of shooting is important to protect your vision.

When using a firearm with mounted optics, maintain an adequate distance between the rear of the scope and your face at all times. Be certain the scope installation does not interfere with access to, or the proper functioning of the safety selector lever.


We specifically disclaim responsibility for any damages or injury whatsoever occurring in connection with, or as a result of, the use of faulty, or non-commercially manufactured, or remanufactured or hand-loaded (reloaded) ammunition. Additionally, we disclaim any responsibility for damage or injury which results from any modifications or changes that are not a part of a firearm as delivered from the factory. We specifically disclaim responsibility for any damages or injury whatsoever occurring in connection with the use of a firearm in conjunction of any Dead Ringer Shooting Sports Products. Dead Ringer does not warrant that this product is commercially viable and we hereby disclose that it has not been tested or approved for use in conjunction with any firearm by any governing body or authority, independent laboratory and or any other public or private testing institutions.

We specifically disclaim responsibility for any damages or injury whatsoever occurring in connection with the use of a firearm. Dead Ringer does not suggest making any modifications or customizations to any firearm whatsoever.

**Please use proper hearing and eye protection at all times whenever firing a weapon.**

### IMPORTANT

Before making any adjustments to the windage and elevation, be sure to loosen the locking screw on the side of the base to avoid damage to the internal components of the sight using the provided screwdriver (marked lock zero). When you have finished zeroing your sight, tighten the locking screw on the base to hold your zero position (marked lock zero).



**Caution: Loosen lock screw before making windage or elevation adjustments using the provided screwdriver**



At Dead Ringer our staff is extremely passionate about design while maintaining that crucial connection to our fellow sportsman. Feedback from everyone in the field has helped us tremendously in developing our products. Our mission is to provide top quality products at an affordable price. Your feedback fuels our innovation!

## INSTRUCTIONS

**CAUTION:** It is better to be safe than sorry. Please be sure that the firearm is unloaded and use proper safe handling of the firearm at all times.

### Specifications include:

- Tubeless design with 24x34mm lens provides a wide field of view, designed for quick target acquisitions for rapid-firing and moving targets applications.
- Green reticle illumination.
- Parallax corrected and unlimited eye-relief.
- Allen head screw type windage and elevation click adjustments, with locking screw.
- Includes a weaver style mounting system.
- Very light weight and shockproof.
- Low power consumption for long battery life.
- Anti-reflection coating.
- Included 3V-CR2032 battery.

## Mounting

The Green Dot incorporates a unique mounting bracket which can be mounted to standard Weaver rails or standard Picatinny rails. To mount the Green Dot to the rails listed above, please loosen up the screws on each side as noted in the drawing for mounting. The lower mounting screw that resides on the front portion of the sight should fit in one of the grooves located at the top of the mounting base. Please make sure that the sight is fully seated on the mounting base before tightening. For some rougher use applications, it is recommended that some form of thread locking adhesive is added to them to ensure a stronger hold.

